


2015 - CX-5 - Body and Accessories


DTC B126A:11 [REAR BODY CONTROL MODULE (RBCM)]

System malfunction location	Front door lock-link switch (LH) lock circuit malfunction
Detection condition	<ul style="list-style-type: none">With the front door lock-link switch (LH) unlocked, the rear body control module (RBCM) detects a short to ground in the front door lock-link switch (LH) lock circuit.
Fail-safe	—
Possible cause	<ul style="list-style-type: none">Front door latch and lock actuator (LH) connector or terminal malfunctionFront door lock-link switch (LH) malfunctionStart stop unit connector or terminal malfunctionRear body control module (RBCM) connector or terminal malfunctionShort to ground in wiring harness between the following terminals:<ul style="list-style-type: none">Start stop unit terminal 1P and front door latch and lock actuator (LH) terminal DRear body control module (RBCM) terminal 3O and front door latch and lock actuator (LH) terminal DStart stop unit malfunctionRear body control module (RBCM) malfunction




RBCM
WIRING HARNESS-SIDE CONNECTOR

3W	3U	3S	3Q	3O	3M	3K	3I	3G	3E	3C	3A
3X	3V	3T	3R	3P	3N	3L	3J	3H	3F	3D	3B




FRONT DOOR LATCH AND LOCK ACTUATOR (LH)
WIRING HARNESS-SIDE CONNECTOR

K	I	G	E	C	A
L	J	H	F	D	B



START STOP UNIT
WIRING HARNESS-SIDE CONNECTOR

1AE	1AC	1AA	1Y	1W	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
1AF	1AD	1AB	1Z	1X	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B



Diagnostic Procedure

Step	Inspection	Action
1	VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN <ul style="list-style-type: none"> Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) Perform the DTC inspection for the rear body 	Yes Go to the next step. No Go to Step 9.

	<p>(See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)</p> <ul style="list-style-type: none"> Is DTC B126A:11 displayed? 		
2	<p>INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (LH) CONNECTOR</p> <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. <p>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</p> <ul style="list-style-type: none"> Disconnect the front door latch and lock actuator (LH) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the connector, then go to Step 8.</p>	
3	<p>INSPECT FRONT DOOR LOCK-LINK SWITCH (LH)</p> <ul style="list-style-type: none"> Inspect the front door lock-link switch (LH). <p>(See DOOR LOCK-LINK SWITCH INSPECTION.)</p> <ul style="list-style-type: none"> Is the front door lock-link switch (LH) normal? 	<p>Yes Go to the next step.</p> <p>No Replace the front door latch and lock actuator (LH), then go to Step 8.</p> <p>(See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.)</p>	
4	<p>INSPECT START STOP UNIT CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the start stop unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the connector, then go to Step 8.</p>	
5	<p>INSPECT REAR BODY CONTROL MODULE (RBCM) CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the rear body control module (RBCM) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the connector, then go to Step 8.</p>	
6	<p>INSPECT FRONT DOOR LOCK-LINK SWITCH (LH) CIRCUIT FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> Verify that the rear body control module (RBCM) connector, start stop unit connector, and front door latch and lock actuator (LH) connector are disconnected. Inspect for continuity between front door latch and lock actuator (LH) terminal D (vehicle wiring 	<p>Yes Repair or replace the wiring harness which is shorted to ground, then go to Step 8.</p> <p>No Go to the next step.</p>	


	<ul style="list-style-type: none"> Is there continuity? 		
7	INSPECT START STOP UNIT <ul style="list-style-type: none"> Inspect the start stop unit. (See START STOP UNIT INSPECTION.) Is the start stop unit normal? 	YesGo to the next step.	
		NoReplace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION .)	
8	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Is DTC B126A:11 displayed? 	YesRepeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.) 	
		NoGo to the next step.	
9	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> Are any other DTCs displayed? 	YesRepair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)] .)	
		NoDTC troubleshooting completed.	

2015 - CX-5 - Body and Accessories






DTC B126A:13 [REAR BODY CONTROL MODULE (RBCM)]

System malfunction location	Front door lock-link switch (LH) lock circuit malfunction
Detection condition	<ul style="list-style-type: none">• Rear body control module (RBCM) detects open circuit in front door lock-link switch (LH) lock side circuit with front door lock-link switch (LH) locked.
Fail-safe	—
Possible cause	<ul style="list-style-type: none">• Front door latch and lock actuator (LH) connector or terminal malfunction• Open circuit in wiring harness between front door latch and lock actuator (LH) terminal J and body ground• Front door lock-link switch (LH) malfunction• Rear body control module (RBCM) connector or terminal malfunction• Open circuit in wiring harness between rear body control module (RBCM) terminal 3O and front door latch and lock actuator (LH) terminal D• Rear body control module (RBCM) malfunction

RBCM



(FRONT DOOR LATCH AND LOCK ACTUATOR (LH

RBCM
WIRING HARNESS-SIDE CONNECTORFRONT DOOR LATCH AND LOCK ACTUATOR (LH)
WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

Step	Inspection	Action
1	VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN <ul style="list-style-type: none"> Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Lock the front door lock-link switch (LH). Is DTC B126A:13 displayed? 	Yes Go to the next step. No Go to Step 8.
2	INSPECT FRONT DOOR LATCH AND LOCK ACTUATOR (LH) CONNECTOR <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Disconnect the front door latch and lock actuator (LH) connector. 	Yes Go to the next step. No Repair or replace the connector, then go to Step 7.

	<p>condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</p> <ul style="list-style-type: none"> Is the connector normal? 		
3	<p>INSPECT FOR OPEN CIRCUIT IN FRONT DOOR LOCK-LINK SWITCH (LH) GROUND CIRCUIT</p> <ul style="list-style-type: none"> Verify that the front door latch and lock actuator (LH) connector is disconnected. Inspect the wiring harness between front door latch and lock actuator (LH) terminal J (vehicle wiring harness side) and body ground for continuity. Is there continuity? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the wiring harness which has an open circuit, then go to Step 7.</p>	
4	<p>INSPECT FRONT DOOR LOCK-LINK SWITCH (LH)</p> <ul style="list-style-type: none"> Inspect the front door lock-link switch (LH). (See DOOR LOCK-LINK SWITCH INSPECTION.) Is the front door lock-link switch (LH) normal? 	<p>Yes Go to the next step.</p> <p>No Replace the front door latch and lock actuator (LH), then go to Step 7. (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.)</p>	
5	<p>INSPECT REAR BODY CONTROL MODULE (RBCM) CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the rear body control module (RBCM) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the connector, then go to Step 7.</p>	
6	<p>INSPECT FOR OPEN CIRCUIT IN FRONT DOOR LOCK-LINK SWITCH (LH) CIRCUIT</p> <ul style="list-style-type: none"> Verify that the rear body control module (RBCM) connector and front door latch and lock actuator (LH) connector are disconnected. Inspect the wiring harness between rear body control module (RBCM) terminal 30 (vehicle wiring harness side) and front door latch and lock actuator (LH) terminal D (vehicle wiring harness side) for continuity. Is there continuity? 	<p>Yes Go to the next step.</p> <p>No Repair or replace the wiring harness which has an open circuit, then go to the next step.</p>	
7	<p>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</p> <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Clear rear body control module (RBCM) DTCs using the M-MDS. 	<p>Yes Repeat the inspection from Step 1.</p> <ul style="list-style-type: none"> If the malfunction recurs, replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.) 	

	<p>(RBCM)].)</p> <ul style="list-style-type: none">• Lock the front door lock-link switch (LH).• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. <p>(See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)</p> <ul style="list-style-type: none">• Is DTC B126A:13 displayed?		
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No	DTC troubleshooting completed.