


SSTs must be used for proper installation!
Proper tightening sequence is required!



SSTs must be used for proper installation!

Proper tightening sequence is required!

12ft·lbf

14.6-20.6ft·lbf

12ft·lbf

14.6-20.6ft·lbf

31ft·lbf

8-9ft·lbf

20ft·lbf

28.1-37.6ft·lbf