

CONTROL SYSTEM

Terminal	Signal	Connected to	Measurement condition	Voltage (V)	Inspection item (s)
1N	Power supply	<ul style="list-style-type: none"> Seat warmer relay*2 Air intake actuator Blower relay Rear blower relay Rear window defroster relay 	Seat warmer switch at ON*2 Ignition switch at ON Ignition switch off	B+ 1.0 or less	<ul style="list-style-type: none"> Seat warmer relay*2 Air intake actuator Blower relay Rear blower relay Rear window defroster relay Related wiring harnesses
1O	Horn control	Horn relay	Transmitter LOCK button is pressed twice within 5 s.	B+ → 1.0 or less → B+	<ul style="list-style-type: none"> Horn relay Related wiring harnesses
1P	—	—	Other	B+	—
2A	Interior light power supply	ROOM 15A fuse	Under any condition	B+	<ul style="list-style-type: none"> ROOM 15A fuse Related wiring harnesses
2B	Hazard power supply	HAZARD 15A fuse	Under any condition	B+	<ul style="list-style-type: none"> HAZARD 15A fuse Related wiring harnesses
2C	Courtesy light power supply	Courtesy light (RH)	Under any condition	B+	<ul style="list-style-type: none"> Courtesy light (RH) Related wiring harnesses
2D	Rear washer motor power supply	Rear washer motor	Ignition switch at ON Ignition switch off	B+ 1.0 or less	<ul style="list-style-type: none"> Ignition switch Rear washer motor Related wiring harnesses
2E	Courtesy light control	Courtesy light (RH)	Within 30 min after any door is opened. 30 min or more after any door is opened. All doors closed	1.0 or less B+ B+	<ul style="list-style-type: none"> Courtesy light (FR) Related wiring harnesses
2F	Power supply	Back-up light relay/position memory control module*5	Ignition switch at ON Ignition switch off	B+ 1.0 or less	<ul style="list-style-type: none"> Back-up light relay Position memory control module*5 Related wiring harnesses
2G	Signal GND	Body ground	Under any condition	1.0 or less	<ul style="list-style-type: none"> Related wiring harnesses
2H	Door lock control (passenger side)	Door lock actuator	Door lock actuator locking Other	1.0 or less → B+ → 1.0 or less 1.0 or less	<ul style="list-style-type: none"> Door lock actuator (passenger side) Related wiring harnesses
2I	Light control	Front side marker light/parking light (LH)	Light switch at TNS Light switch off	B+ 1.0 or less	<ul style="list-style-type: none"> TNS relay Related wiring harnesses
2J	—	—	—	—	—
2K	Light control	Front side marker light/parking light (RH)	Light switch at TNS Light switch off	B+ 1.0 or less	<ul style="list-style-type: none"> TNS relay Related wiring harnesses
2L	Door unlock control (passenger side)	Door lock actuator	Door lock actuator unlocking Other	1.0 or less → B+ → 1.0 or less 1.0 or less	<ul style="list-style-type: none"> Door lock actuator (passenger side) Related wiring harnesses
2M	IG1	Check connector	Ignition switch at ON Ignition switch off	B+ 1.0 or less	<ul style="list-style-type: none"> Check connector Related wiring harnesses
2N	Power GND	Body ground	Under any condition	1.0 or less	<ul style="list-style-type: none"> Related wiring harnesses