

ON-BOARD DIAGNOSTIC [DYNAMIC STABILITY CONTROL (DSC)]

DTC C0031:01/C0034:01/C0037:01/C003A:01 [DYNAMIC STABILITY CONTROL (DSC)]

id0402b2877300

DTC	C0031:01 C0034:01 C0037:01 C003A:01	LF ABS wheel-speed sensor RF ABS wheel-speed sensor LR ABS wheel-speed sensor RR ABS wheel-speed sensor
DETECTION CONDITION	• Open circuit or short to ground has been detected in the ABS wheel-speed sensor wiring harness on any of the four vehicle wheels.	
POSSIBLE CAUSE	• Open circuit or short to ground in the wiring harness between the following DSC HU/CM terminals and ABS wheel-speed sensor terminals: — DSC HU/CM terminal AP—RF ABS wheel-speed sensor terminal A — DSC HU/CM terminal AS—RF ABS wheel-speed sensor terminal B — DSC HU/CM terminal I—LF ABS wheel-speed sensor terminal A — DSC HU/CM terminal F—LF ABS wheel-speed sensor terminal B — DSC HU/CM terminal O—RR ABS wheel-speed sensor terminal A — DSC HU/CM terminal R—RR ABS wheel-speed sensor terminal B — DSC HU/CM terminal AJ—LR ABS wheel-speed sensor terminal A — DSC HU/CM terminal AG—LR ABS wheel-speed sensor terminal B • Malfunction in the ABS wheel-speed sensor • Poor connection at connectors (female terminal)	

